

Seatpost Installation

American Classic New Style Seatpost Installation. Designed To Work With Industry Standard 7mm Round Saddle Rails.

NOTE: All older seatposts and older seatpost parts have been discontinued and are no longer in stock.
Tools Needed: Torque wrench with 4mm hex key.



Step 1: With the saddle resting top side down, position the cradle plate as shown on the rails.



Step 2: Position the two lower clamps as shown. The clamps rest on the cradle plate and rails.



Step 3: Press the top of the seatpost down into position while sliding the 2 lower clamp pieces into place.



Step 4: While holding the lower clamp pieces in place, install the 4mm hex bolt (lightly greased). Do not tighten completely.



Step 5: Install the seatpost in the bike and then micro adjust accordingly. Torque Specification: 35 inch-pounds or 4 N-M.

NOTE: Always remember to keep bolt, threads and surface contact points clean. Preventative maintenance will extend the life of your bike. Inspect your post and assembly periodically. Discontinue using if you find signs of wear, damage or corrosion on your seatpost.